


SC-SC-SET, 1-volume and 2-tone with 5-way switch and 2 push-pull's



5-way blade switch	
Pos.1	Neck
Pos.2	Neck/Middle
Pos.3	Mid
Pos.4	Middle/Bridge
Pos.5	Bridge

Tone2 push- push	Tone1 push-push	
	Down	Up
Down	HB	
Up	SE	SET