


SET-SC-SET, 1-volume and 2-tone with 5-way switch, 3 push-pull's

1st tone for Neck/Mid
and 2nd tone for Bridge



5-way blade switch	
Pos. 1	Neck
Pos. 2	Neck/Middle
Pos. 3	Middle
Pos. 4	Middle/Bridge
Pos. 5	Bridge

		2nd push-push	
		Dn	Up
1st/ 3rd Push- push	Dn	HB	
	Up	SE	SET