


SET-SET, 3-way blade switch, 1-volume and 1-tone Made for Fender Thinline Telecaster model



3-way blade switch

Pos.1	Neck
Pos.2	Neck/Middle
Pos.3	Mid

Push-push

Down	HB
Up	SE